

	Troubleshooting Guide: How to Find Accumulated Time and Distance	
Prepared by: Kevin Oeltjenbruns	Date Prepared: 2/26/2021	Models Affected: Current Retail and IPO Treadmills

OVERVIEW

Use this guide to find the accumulated time and distance on a retail or IPO treadmill.

INSTRUCTIONS

Models T101, T202, T303, 7.0AT, 7.4AT, Elite T5, Elite T7 Elite T9, T80 Classic, and XR Consoles:

- 1) Press and hold the Incline Up (plus) and Speed Down (minus) keys simultaneously for 3-5 seconds.
- 2) Use the Speed keys to navigate to Eng4 and hit Enter.
- 3) Use the Speed keys to navigate the menu to Accumulated Info and hit Enter. The console will now display Accumulated Time and Accumulated Distance.
- 4) Press and hold the Stop key for 3-5 seconds or cycle power on the unit or console to reset to normal function.

Model 7.8AT:

- 1) Use the Incline Level 15 and Speed Level 12 keys instead of the Incline Up / Speed Down keys listed above in Step 1. Otherwise, the instructions for navigating the menu and finding the Accumulated data are identical.

Models T80 Elegant+ and T80 Touch+:

- 1) Press and hold the Incline Up (plus) and Speed Down (minus) keys simultaneously for 3-5 seconds.
- 2) The console will now display Accumulated Time and Accumulated Distance.
- 3) Press the Home button on the top left side of the screen to reset to normal function.

Model T600:

- 1) Press and hold the Incline Down (minus) and Speed Down (minus) keys simultaneously for 3-5 seconds.
- 2) Use the Speed keys to navigate the menu to P7 (Accumulated Distance) or P8 (Accumulated Time) and hit Enter. Press the Stop key to return to the previous screen.

- 3) Press and hold the Stop key for 3-5 seconds or cycle power on the unit or console to reset to normal function.

Model T130x:

- 1) Press Enter (check mark), 3, 0, 0, 1, Enter on the number pad.
- 2) Use the Speed keys to navigate to Accumulate and press Enter to select.
- 3) Use the Speed keys to navigate to Distance or Time and press Enter to display the data. Press the Back key to return to the previous screen.
- 4) Press and hold the Stop key for 3-5 seconds or cycle power on the unit or console to reset to normal function.

Model T130xi:

- 1) Press and hold the Matrix logo at the top of the welcome screen for 5 seconds.
- 2) After the number keypad appears, press 1, 0, 0, 1, Enter.
- 3) Accumulated Distance and Time will be displayed under the General section.
- 4) Cycle power on the unit or console to reset to normal function.

XER, XIR, and XUR Consoles:

- 1) Press the Gear Icon in the upper right-hand corner of the home screen.
- 2) Select Machine Settings from the menu.
- 3) Accumulated Distance and Time will be displayed under the General section.
- 4) Cycle power on the unit or console to reset to normal function.